


Whirlpool CSP2760KQ1 03 - CONTROL PANEL AND SEPARATOR



Whirlpool Commercial Whirlpool CSP2760KQ1 Dryer Parts Parts Diagram 03 - CONTROL PANEL AND SEPARATOR

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8283294			Harness, Wire 1a 692998
"	692998			Receptacle
2	3400000			Screw, 10-24 X 3/8
3	3391018			Tie Cable
4	697776	4331106		Screw, No.10-32 X 7/16
5	98139	303776		Screw
6	3390115			Bracket, Timer
7	3389668	279737		Timer
8	3387974			Timing Cam
"	339855			Timing Cam
"	343777			Timing Cam
"	339854			Timing Cam
"	339853			Timing Cam
9	385421			Funnel, Coin
10	303921	489128		Screw, 8-32 X 27/64
11	3954761	279950		Funnel

12	3979100		Panel, Control
13	8527831	8565384	Insert, Decorative
14	3979325		Lamp, Indicator
"	3979326		Lamp, Indicator
"	3979327		Lamp, Indicator
15	354239		Rivet
16	8283296		Wire Jumper
17	8316437	W10330137	Switch, Pushbutton
18	8316433		Pushbutton
19	3397659		Block, Terminal
20	3401699		Jumper Wire
21	279318		Terminal Tinned And Brass Panel
22	3400500		Bolt, 3405245 5/16-18 X 3/4
23	3978853		Collar
24	279393		Terminal Block Screw Kit
25	96435	356418	Screw
26	3400094		Screw, 10-32 X 3/8
27	3396795		Cover, Terminal Block
28	3390443		Retainer, Terminal
29	8316523		Extension
30	3400086		Screw, 10-32 X 3/8
31	8316520		Slide Mechanism Inserts
"	8316264	4396666	Insert
"	8316265	4396667	Insert
32	8316525	4396671	Box
33	BLANK	Not Available	Key (Money Box) (When Ordering, Specify Vendor and Key Number)
34	8316526	4396668	Lock-Cam
35	BLANK	Not Available	Key (Service Door) (When Ordering, Specify Vendor and Key Number)
36	8318517	8576635	Bolt
39	3390424		Extension, Slide

