


Whirlpool CSP2760TQ2 01 - LOWER CABINET AND FRONT PANEL PARTS



Whirlpool [Commercial Whirlpool CSP2760TQ2 Dryer Parts](#) Parts Diagram 01 - LOWER CABINET AND FRONT PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10184585		Not Available	Installation Instructions
"	8576825			Wiring Diagram
"	W10184611		Not Available	REPAIR PARTS LIST
2	693152			Bumper, Console
3	3390663	681414		Screw, 10AB X 1/2
4	3391846			Clip, Front Panel
5	3394881	279782		Switch-Lid
6	3393258	3373329D		Screw
7	8310656			Cabinet
8	3392100	49621		Feet-Leveling
9	W10121316			Plug, Multivent
10	3387374			Spring, Idler
11	3389420			Retainer-Idler 1/4-20 X 1/16
12	697773	3395530		Screw
13	3388672	279640		Pulley-ldr

14	3391915	681615	Screw
15	3392918	3396122	Window Pack. Includes Illustration 15 And 25)
16	W10167612		Wire, Broken Belt Switch
17	718032		Screw, 8-18 X 3/4
18	W10121334		Washer, Thrust
19	297092		Clip
20	690997		Washer, Thrust
21	3389247		Hinge And Pin Assembly
22	3392914		Frame, Window
23	8066120		Lever, Door Switch
24	3390647	488729	Screw
25	3392915		Gasket, Window
26	3389249		Nut, Inner Door
27	8538264	W10438970	Motor-Drive
28	3398948		Wire, Jumper
29	8066184		Pulley, Motor
30	3387610	661570	Belt
31	3390902		Clip, Door Hinge
32	3387118		Bracket, Motor
33	3392186	4159590	Washer
34	8529992		Harness
"	692997		Plug, Multi- Terminal
"	717252		Receptacle, Terminal
35	3390735		Seal, Door
36	3392538	279570	Latch
37	9742177		Screw, 8-18 X .625
38	8283298		Jumper, Door Switch
"	717253		Receptacle
"	3936144		Do-It-Yourself Repair Manuals
39	3388674	W10118756	Idler Bracket
40	W10213202		Handle, Door
41	3406109	3406107	Door Switch Assembly
42	98129		Screw, 6-20 X 1 1/16
43	697215	3406797	Toe Panel
44	3387242		Seal, Front Panel
45	342055	488627	Screw
46	3388229		Retainer, Toe Panel
47	W10205622	W10244331	Door-Rear
48	694091		Trim, Side Right Hand
49	W10205649		Door, Front
50	3391018		Tie Cable
51	W10192882	W10242810	Panel
52	696144	279570	Latch
53	697750	W10470674	Dryer Exhaust Kit
54	279731	49026	4" - 90° Elbow
55	488729		Screw
56	3394331		Plate Cover
57	W10191265		Plug, Hinge Screw Front Panel
58	279818	W10470674	Dryer Exhaust Kit