


Whirlpool CSP2760TQ2 02 - CONTROL PANEL AND SEPARATOR PARTS



Whirlpool Commercial Whirlpool CSP2760TQ2 Dryer Parts Parts Diagram 02 - CONTROL PANEL AND SEPARATOR PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8576522			Harness, Wire
"	692998			Receptacle
2	3400000			Screw, 10-24 X 3/8
3	3391018			Tie Cable
4	697776	4331106		Screw, No.10-32 X 7/16
5	98139	303776		Screw
6	3390115			Bracket, Timer
7	3389668	279737		Timer
8	3387974			Timing Cam
"	339855			Timing Cam
"	343777			Timing Cam
"	339854			Timing Cam
"	339853			Timing Cam
9	385421			Funnel, Coin
10	303921	489128		Screw, 8-32 X 27/64
11	3954761	279950		Funnel

12	3979100		Panel, Control
13	8565384		Insert, Decorative
14	3979325		Lamp, Indicator
"	3979326		Lamp, Indicator
"	3979327		Lamp, Indicator
15	354239		Rivet
16	8283296		Wire Jumper
17	8316437	W10330137	Switch, Pushbutton
18	8316433		Pushbutton
19	3397659		Block, Terminal
20	8539882	3401699	Jumper Wire
21	279318		Terminal Tinned And Brass Panel
22	3400500		Bolt, 3405245 5/16-18 X 3/4
23	3978853		Collar
24	279393		Terminal Block Screw Kit
25	3400029		Nut, Adapter Plate
26	3400094		Screw, 10-32 X 3/8
27	3396795		Cover, Terminal Block
28	3390443		Retainer, Terminal
29	3401699		Jumper Wire
30	353424		Plug, Terminal
31	98997		Clip, Harness Following Parts Optional Are Not Supplied On This Whirlpool Model. But Are Available For Purchase.
32	96435	356418	Screw
33	8316520		Slide Mechanism Inserts
"	8316264	4396666	Insert
"	8316265	4396667	Insert
34	8316525	4396671	Box
35	BLANK	Not Available	Key (Money Box) (When Ordering, Specify Vendor and Key Number)
36	8316526	4396668	Lock-Cam
37	BLANK	Not Available	Key (Service Door) (When Ordering, Specify Vendor and Key Number)
38	8318517	8576635	Bolt
39	3390424		Extension, Slide
40	W10135246	Not Available	BAG ASSEMBLY

the laundry company[®]