


Whirlpool CSP2761HW0 03 - CONTROL PANEL AND SEPARATOR



Whirlpool [Commercial Whirlpool CSP2761HW0 Dryer Parts](#) Parts Diagram 03 - CONTROL PANEL AND SEPARATOR
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3406276			Harness, Wire
2	3400000			Screw, 10-24 X 3/8
3	3391018			Tie Cable
4	697776	4331106		Screw, No.10-32 X 7/16
5	98139	303776		Screw
6	3390115			Bracket, Timer
7	3389668	279737		Timer
8	3387974			Timing Cam
"	343777			Timing Cam
9	3389224			Funnel, Coin
12	3391955		Not Available	Panel, Control
13	3406132		Not Available	Insert, Decorative
14	3349305			Lens, Light
15	354239			Rivet
16	3949703			Knob
17	3387810			Switch, Cycle

18	3388231		Switch, Push- To-Start
19	3390189		Strain Relief
20	3390895	3393463	Strut
21	340025	687133	Wire
22	3400500		Bolt, 3405245 5/16-18 X 3/4
23	3402385	3978853	Collar
24	688805		Clip, Spring Knob
25	96435	356418	Screw
26	98437	595095	Screw, 10-32 X 3/8
27	3396795		Cover, Terminal Block
28	3390443		Retainer, Terminal
29	3401402		Cord, Power
30	3390424		Extension, Slide

the laundry company[®]

the laundry company[®]

the laundry company[®]