


Whirlpool CSP2761TQ1 02 - CONTROL PANEL AND SEPARATOR PARTS



Whirlpool Commercial Whirlpool CSP2761TQ1 Dryer Parts Diagram 02 - CONTROL PANEL AND SEPARATOR PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8283295			Harness, Wire
2	3400000			Screw, 10-24 X 3/8
3	3391018			Tie Cable
4	697776	4331106		Screw, No.10-32 X 7/16
5	98139	303776		Screw
6	3390115			Bracket, Timer
7	3389668	279737		Timer
8	3387974			Timing Cam
"	339855			Timing Cam
"	343777			Timing Cam
"	339854			Timing Cam
"	339853			Timing Cam
9	385421			Funnel, Coin
10	303921	489128		Screw, 8-32 X 27/64
11	3954761	279950		Funnel
12	3979100			Panel, Control

13	8527831	8565384	Insert, Decorative
14	3979325		Lamp, Indicator
"	3979326		Lamp, Indicator
"	3979327		Lamp, Indicator
15	354239		Rivet
16	8283296		Wire Jumper
17	8316437	W10330137	Switch, Pushbutton
18	8316433		Pushbutton
19	3390189		Strain Relief
20	8539882	3401699	Jumper Wire
21	3400029		Nut, Adapter Plate
22	3400500		Bolt, 3405245 5/16-18 X 3/4
23	3978853		Collar
24	3401402		Cord, Power
25	3401699		Jumper Wire
26	3400094		Screw, 10-32 X 3/8
27	3396795		Cover, Terminal Block
28	3390443		Retainer, Terminal
29	353424		Plug, Terminal
30	94614		Terminal
31	94613	596797	Terminal
32	3395683		Receptacle, Multi-Terminal
33	3403498		Connector, 3-Position
34	3403499		Connector, 2-Position
35	98997		Clip, Harness Following Parts Optional Are Not Supplied On This Whirlpool Model. But Are Available For Purchase.
36	96435	356418	Screw
37	8316520		Slide Mechanism Inserts
"	8316264	4396666	Insert
"	8316265	4396667	Insert
38	8316525	4396671	Box
39	BLANK	Not Available	Key (Money Box) (When Ordering, Specify Vendor and Key Number)
40	8316526	4396668	Lock-Cam
41	BLANK	Not Available	Key (Service Door) (When Ordering, Specify Vendor and Key Number)
42	8318517	8576635	Bolt
43	3390424		Extension, Slide
44	3390615		Screw And Cam Bag Assembly