


Whirlpool CSP2771EW0 03 - CONTROL PANEL AND SEPARATOR

CONTROL PANEL AND SEPARATOR PARTS

For Model: CSP2771EW0
(White)



881658

3

Whirlpool [Commercial Whirlpool CSP2771EW0 Dryer Parts](#) Parts Diagram 03 - CONTROL PANEL AND SEPARATOR
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3406276			Harness, Wire
2	3400000			Screw, 10-24 X 3/8
3	3391018			Tie Cable
4	697776	4331106		Screw, No.10-32 X 7/16
5	98139	303776		Screw
6	3977294			Card Reader Assembly
"	3977295			Card Reader Assembly
"	3977296			Card Reader Assy. (Screw (2))
7	3977290			Harness, Console
"	3972291			Harness, Console (Lower)
8	3977289			Control Board
9	3393909			Screw, 8-32 X 7/8
10	3977293			Bracket, Relay
11	3977300			Bolt, 4-40 x 1/2
12	3391955		Not Available	Panel, Control
13	3406132		Not Available	Insert, Decorative

14	3349305		Lens, Light
15	354239		Rivet
16	3949703		Knob
17	3387810		Switch, Cycle
18	3388231		Switch, Push- To-Start
20	3390895	3393463	Strut
21	340025	687133	Wire
22	3400500		Bolt, 3405245 5/16-18 X 3/4
23	3402754	3978853	Collar
24	688805		Clip, Spring Knob
27	3396795		Cover, Terminal Block
28	3390443		Retainer, Terminal
29	697812	8566493	Power Relay
30	3977301		Nut, 4-40
31	3977302		Lockwasher No.4
32	3401402		Cord, Power

