


Whirlpool CSP2791BW0 02 - CONTROL PANEL AND SEPARATOR



Whirlpool [Commercial Whirlpool CSP2791BW0 Dryer Parts](#) Parts Diagram 02 - CONTROL PANEL AND SEPARATOR
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3402412			Harness, Wire
"	385826	94696		Plug, Terminal
"	3936113			Receptacle
2	3400000			Screw, 10-24 X 3/8
4	3392891	303776		Screw
5	3393909			Screw, 8-32 X 7/8
6	3361361		Not Available	Bracket, Relay
7	3396010			Timer, Electronic
8	697812	8566493		Power Relay
9	3402410			Switch-Service Door
10	3402409		Not Available	Switch-Coin Simulator
11	3402408			Switch, Power Interrupt
12	3389625			Panel, Control
13	3402401			Insert, Decorative
14	3389520			Lens, Light (6)
15	356388	680771		Rivet

16	3401177		Light, Indicator Assembly
17	3401851		Switch, Pushbutton
18	3348587		Button, Pushbutton
19	3390189		Strain Relief
20	3393463		Strut
21	340025	687133	Wire
22	172455	3400500	Bolt, 3405245 5/16-18 X 3/4
23	3402385	3978853	Collar
"	3402386	Not Available	Collar (Almond)
24	311932	313808	Screw
25	697773	3395530	Screw
26	3402411		Switch, Money Vault
27	3396795		Cover, Terminal Block
28	3390443		Retainer, Terminal
29	697776	4331106	Screw, No.10-32 X 7/16
30		Not Available	
31		Not Available	
32		Not Available	
33	2170653	2151749	Crisper Cover
34	BLANK	Not Available	Security Lock & Cam Assembly
35	BLANK	Not Available	Key, Service Door
36		Not Available	
37	3401402		Cord, Power
NI	717252		Receptacle, Terminal
39	303921	489128	Screw, 8-32 X 27/64
40	3391018		Tie Cable
41	3393439	489069	Xxscrew, 10-12 X 1/2
45	359702	W10491983	Tip-Tines
46	312717	Not Available	Screw, 4.40 x 3/4
47	3402423	Not Available	Harness Accountability (2)

