


Whirlpool GCAM2792TQ0 01 - TOP AND CABINET PARTS



Whirlpool [Commercial Whirlpool GCAM2792TQ0 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8524748		Not Available	Installation Instructions
"	8316464			Use & Care Guide
"	W10143395			Wiring Diagram
"	W10172197			Energy Guide
"	W10114746			Repair Parts List
2	W10173243	W10193874		Lid
3	9724509			Bumper, Lid
4	358684			Strike, Lid Switch
5	W10119828			Screw, Lid Hinge Mounting
6	54583			Hinge, Lid
7	19119			Bumper, Lid Hinge
8	54584			Hinge, Lid
9	3352629	285671		Switch-Lid
10	3390631			Screw, 10-16 X 3/8
11	62780			Clip, Top And Cabinet And Rear Panel
12	358473			Nut, Push-In

13	8524697	Top
14	21258	Bearing, Lid Hinge
15	3356311	Screw And Washer, Lid Switch Shield
16	3362952	Dispenser, Bleach
17	90016	Clip, Pressure Switch Hose
18	62750	Spacer, Cabinet To Top (4)
19	63424	Cabinet

