


Whirlpool GCAM2792TQ0 03 - AGITATOR, BASKET AND TUB PARTS



W10114746

6

Whirlpool [Commercial Whirlpool GCAM2792TQ0 Washer Parts](#) Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	63580			Dispenser, Fabric Softener
2	3354733	W10074580		Cap, Barrier
3	W10072840			Fabric Softener
4	358237			Screw And Washer
5	3949550			Washer
6	3348117	285565		Agitator
7	3363663	285811		Cam-Agitator
8	3366877	80040		Dog-Agitator
9	3363661			Bearing, Driven Cam
10	3348752			Mover, Clothes
11	3350389	285587		Washer
12	3347288			Agitator
13	8528150	W10445870		Ring-Tub
14	3976308			Gasket, Tub Ring
15	3354845			Clip, Agitator
16	8543666			Washer, Agitator

17	21366		Nut, Spanner
18	387240		Ring, Balance
19	8526016	W10389328	Clothes Container, Assembly
20	W10135425	63849	Strain Relief, Power Cord
21	389140		Tub Block, Basket Drive
22	383727		Gasket, Centerpodt

