


Whirlpool GCAM2792TQ0 06 - CONTROL PANEL PARTS



W10114746

10

Whirlpool [Commercial Whirlpool GCAM2792TQ0 Washer Parts](#) Parts Diagram 06 - CONTROL PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8524796			Panel, Console
2	8524798			Bracket, Control
3	97787	W10109200		Screw, Baffle Mounting
4	8316435	W10330136		Switch, Cycle Selector
5	3393918	355214		Screw And Washer
6	3949737			Cap, End
7	W10129718	W10339325		Switch-WL
8	W10116523			Timer
9	3400073			Screw, Ground
10	8274412			Dial, Timer
11	8529311			Knob, Timer
12	8316433			Pushbutton
13	8524802	W10339319		Switch-WL
14	W10136114			Harness, Wiring
15	3398893	3395559		Wire
16	3949734	W10096320		Cap, End

17	689559		Nut, Push-In
18	388326		Screw, 8-18 X 1.25
19	8524801	353244	Hose, Pressure Switch
20	8533269	353244	Hose, Pressure Switch
21	357572	W10113937	Clip, Grounding
22	BLANK	Not Available	Hose, Pressure Switch to ``T`` (Part Non- Serviceable)
23	BLANK	Not Available	Fitting, Pressure Hose ``T`` (Part Non- Serviceable)

