


Whirlpool GCEM2990TQ0 03 - CABINET PARTS, OPTIONAL PARTS (NOT INCLUDED)



W10119635

6

Whirlpool [Commercial Whirlpool GCEM2990TQ0 Dryer Parts](#) Parts Diagram 03 - CABINET PARTS, OPTIONAL PARTS (NOT INCLUDED)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3394083			Clip, Front Panel
2	388326			Screw, 8-18 X 1.25
3	8541400			Bracket, Cabinet
4	343641	681414		Screw, 10AB X 1/2
5	279393			Terminal Block Screw Kit
6	3403630			Plug, Strike Hole
7	3393008	308685		Side Trim)
8	697776	4331106		Screw, No.10-32 X 7/16
9	3397659			Block, Terminal
10	697773	3395530		Screw
11	279318			Terminal Tinned And Brass Panel
12	3405184			Handle, Door
13	3402335			Door, Front
14	3402341			Door, Inner

15	3396795		Cover, Terminal Block
16	8066217		Hinge, Top
17	342055	488627	Screw
18	3396805	280043	Panel-Rear
19	3405514	W10362431	Hinge And Pin Assembly
20	690363	18776	Lock, Front Top
21	98234		Clip, U-Bend
22	3406129		Seal And Bearing Assembly
23	693995		Screw, Hex Head
24	3403444	279852	Panel
25	3392100	49621	Feet-Leveling
"	279810		Foot-Optional
26	3404413		Plug, Hinge Hole
27	3403431		Strike, Panel
28	8530603	8533643	Cabinet
29	3405246		Seal, Door Push-To-Start
30	3406109	3406107	Door Switch Assembly
31	8066184		Pulley, Motor
32	660658		Clamp, Motor Mounting 343481 685441
33	3404162		Clamp, Motor
34	685203	279220	Clip
35	691366		Idler And Pulley Assembly
36	3400500		Bolt, 3405245 5/16-18 X 3/4
37	3389441		Door Catch Assembly
38	8066206	279827	Motor-Drve
39	348780		Base, Motor
40	W10131364	341241	Belt
	BLANK	Not Available	ACCESSORY PARTS
"	279948	4392065	Kit, Dryer Repair
"	8522199		Accessory Parts
"	72017		Paint, Touch-Up
"	350930		Paint, Pressurized Spray B
"	350938		Paint, Pressurized Spray B
"	799344		Paint, Touch-Up)

