


Whirlpool GCGM2991LQ0 02 - TOP AND CONSOLE, LITERATURE



Whirlpool Commercial Whirlpool GCGM2991LQ0 Dryer Parts Parts Diagram 02 - TOP AND CONSOLE, LITERATURE
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|---------------------------|---------------|-----------------------------------------------|
| 1 | LIT8527907 | | Not Available | Literature Parts (Use & Care Guide) |
| " | LIT8528203 | | Not Available | Literature Parts (Wiring Diagram) |
| " | LIT8527902 | | Not Available | Literature Parts (Instructions, Installation) |
| " | LIT8527901 | | Not Available | Literature Parts (Repair Parts List) |
| 2 | 8283378 | | | Cover, Lint Screen |
| 3 | 8316433 | | | Pushbutton |
| 4 | 8316437 | W10330137 | | Switch, Pushbutton |
| 5 | 357572 | W10113937 | | Clip, Grounding |
| 6 | 3949737 | | | Cap, End |
| 7 | 97787 | W10109200 | | Screw, Baffle Mounting |
| 8 | 3949734 | W10096320 | | Cap, End |
| 9 | 8527826 | | | Panel, Control |
| 10 | 349639 | | | HAndle And Lint Screen Assembly |

| | | | |
|----|-------------------------|---------------------------|-----------------------------------|
| 11 | 8527828 | | Bracket, Control |
| 12 | 3978606 | | Hinge, Lint Lid |
| " | 3978605 | W10044470 | Hinge, RH |
| 13 | 688983 | 487240 | Screw, For Mtg. Service Capacitor |
| 14 | 8066156 | | Panel, Rear |
| 15 | 357213 | | Nut, Push-In |
| 16 | 8316630 | | Top |
| 17 | 297535 | 17258 | Bumper |
| 18 | 303921 | 489128 | Screw, 8-32 X 27/64 |
| 19 | 3979596 | | Timer |
| 20 | 3390646 | W10139210 | Screw, 8-18 X 5/16 |
| 21 | 693995 | | Screw, Hex Head |
| 22 | 339554 | 3390631 | Screw, 10-16 X 3/8 |
| 23 | 3393811 | | Wire, Jumper |
| " | 3393812 | | Wire, Jumper |
| 24 | 3398893 | 3395559 | Wire |
| 25 | 8529317 | | Knob, Timer |
| 26 | 8299876 | | Harness, Wiring |
| 27 | 94614 | | Terminal |
| 28 | 717252 | | Receptacle, Terminal |
| 29 | 3395683 | | Receptacle, Multi-Terminal |
| 30 | 689559 | | Nut, Push-In |
| 31 | 3403498 | | Connector, 3-Position |
| 32 | 3403499 | | Connector, 2-Position |
| 33 | 3936144 | | Do-It-Yourself Repair Manuals |
| 34 | 3394427 | | Clip-Harness |
| 35 | 3397269 | | Connector, Timer |

the laundry company[®]

the laundry company[®]