


Whirlpool QCAM2730YQ0 01 - TOP AND CABINET PARTS



Whirlpool [Commercial Whirlpool QCAM2730YQ0 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8524739		Not Available	Installation Instructions
"	W10135801			Wiring Diagram
2	8524688			Top
3	3353950			Spacer, Cabinet To Top
4	3351614			Screw, Gearcase Cover Mounting
5	3358500			Panel, Front
6	62780			Clip, Top And Cabinet And Rear Panel
7	358473			Nut, Push-In
8	3400611			Screw And Washer, Lid Switch
9	90406			Cage Nut, 5/16-18
10	3353948			Bracket, Lock
11	8054980			Switch, Lid
12	63554			Rivet
13	W10119828			Screw, Lid Hinge Mounting
14	21097			Pad, Lid Hinge

15	8524784		Hinge, Lid
16	54583		Hinge, Lid
17	19119		Bumper, Lid Hinge
18	21258		Bearing, Lid Hinge
19	W10171146	W10193854W10193854	Lid
20	387371		Lock, Plug Also Available
21	3353812		Locator
22	356908		Bumper, Lid
23	3400804	98165	Screw
24	W10004930		Clip, U-Bend
25	3353993		Screw 10-16 X .690
26	356907		Rivet, Plastic
27	3393258	3373329D	Screw
28	3976380		Panel, Right Hand
29	3976382		Panel, Left Hand
30	3353949		Pin, Locator
31	18776		Lock, Front Top

