


Whirlpool QCAM2730YQ0 02 - CONTROL PANEL PARTS

CONTROL PANEL PARTS

For Model: QCAM2730YQ0
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

W10474994

4

Whirlpool [Commercial Whirlpool QCAM2730YQ0 Washer Parts](#) Parts Diagram 02 - CONTROL PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10470741			Panel, Console
2	3978858			Bracket, Control
3	W10113937			Clip, Grounding
4	W10330140			Switch, Cycle Selector
5	3390646	W10139210		Screw, 8-18 X 5/16
6	3949740			End Cap
7	8281182			Screw, 8-18 X 1 1/4
8	W10414164			Pressure Switch, High Water Level
9	3352457			Lights, Indicator
10	3348109			Lens Light
11	3348110			Lens, Yellow
12	8316433			Pushbutton
13	W10414162			Pressure Switch, Low Water Level
14	3400073			Screw, Ground
15	00767			Screw, 8A X 3/8 HeX Washer

15	3949734	W10096320	Head Tapping
16	689559		Cap, End
17	97787	W10109200	Nut, Push-In
18	W10138030		Screw, Baffle Mounting
19	8578168		Harness, Console Wiring
20	W10231379	W10251893	Control, Automatic Temp.
21			Clamp-Hose

