



"	53-0162		Not Available	BUTTON, GAS ACCESS (ALM)
10	25-7817		Not Available	CLIP, U-TYPE
"	25-7820	<a href="#">489478</a>		Screw, 8 X 1/2
11	<a href="#">25-7220</a>			Clip, Cabinet Top
12	63-6148	<a href="#">53-0643</a>		Pin, Locator
13	25-0224	<a href="#">3400029</a>		Nut, Adapter Plate
"	<a href="#">53-0200</a>			Sleeve, Locator Pin
14	25-7810	<a href="#">415013-35</a>		Screw
"	53-0917	<a href="#">12001324</a>		Duct Kit, Collector
15	<a href="#">53-0204</a>			Seal
16	<a href="#">53-0123</a>			Clip
17	<a href="#">53-0701</a>			Lint Screen
"	<a href="#">53-0918</a>			Filter, Lint
18	53-0282	<a href="#">31001637</a>		Seal Assembly, Cylinder Front
19	53-0154-25		Not Available	PANEL, OUTER DOOR (H WHT)
20	53-0740		Not Available	INNER DOOR
"	53-0104	<a href="#">LA-1024</a>		Inner Door Kit
21	<a href="#">53-0119</a>			Clip, Hinge
22	53-0251	<a href="#">53-1490</a>		Door Pad
23	53-0252	<a href="#">53-1491</a>		Door Pad
24	25-7770	<a href="#">3196169</a>		Screw, Element
"	53-0648	<a href="#">31001529</a>		Seal, Door
25	25-3534	<a href="#">25-7889</a>		Plug Button
26	53-0116	<a href="#">53-0927</a>		Handle, Door
"	25-7810	<a href="#">415013-35</a>		Screw
27	53-0122	<a href="#">53-1492</a>		Hinge, Dryer Door
28	53-0121		Not Available	TWIN NUT
"	<a href="#">25-7809</a>			Screw, No.6-20 1/2 Flthd Torx
"	<a href="#">LA-1003</a>			Door Catch Kit
29	73-0033	<a href="#">LA-1003</a>		Door Catch Kit
30	73-0034	<a href="#">LA-1003</a>		Door Catch Kit
32	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE SCREW-PURCHASED LOCALLY
"	53-0283		Not Available	COVER
34	<a href="#">LA-1005</a>			Switch Kit
"	53-0772	<a href="#">21001495</a>		Rack, Drying
35	<a href="#">53-0148</a>			Switch, Door
36	63-5990	<a href="#">31001319</a>		Clip, Switch

*the laundry company*<sup>®</sup>