

"	53-0162		Not Available	BUTTON, GAS ACCESS (ALM)
10	25-7817		Not Available	CLIP, U-TYPE
"	25-7820	489478		Screw, 8 X 1/2
11	25-7220			Clip, Cabinet Top
12	63-6148	53-0643		Pin, Locator
13	25-0224	3400029		Nut, Adapter Plate
"	53-0200			Sleeve, Locator Pin
14	25-7810	415013-35		Screw
"	53-0917	12001324		Duct Kit, Collector
15	53-0204			Seal
16	53-0123			Clip
17	53-0701			Lint Screen
"	53-0918			Filter, Lint
18	53-0282	31001637		Seal Assembly, Cylinder Front
19	53-0154			Panel, Outer Door
20	53-0740		Not Available	INNER DOOR
"	53-0104	LA-1024		Inner Door Kit
21	53-0119			Clip, Hinge
22	53-0251	53-1490		Door Pad
23	53-0252	53-1491		Door Pad
24	25-7770	3196169		Screw, Element
"	53-0648	31001529		Seal, Door
25	25-3534	25-7889		Plug Button
26	53-0116	53-0927		Handle, Door
"	25-7810	415013-35		Screw
27	53-0122	53-1492		Hinge, Dryer Door
28	53-0121		Not Available	TWIN NUT
"	25-7809			Screw, No.6-20 1/2 Flthd Torx
"	LA-1003			Door Catch Kit
29	73-0033	LA-1003		Door Catch Kit
30	73-0034	LA-1003		Door Catch Kit
32	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE SCREW-PURCHASED LOCALLY
"	53-0283		Not Available	COVER
34	LA-1005			Switch Kit
"	53-0772	21001495		Rack, Drying
35	53-0148			Switch, Door
36	63-5990	31001319		Clip, Switch

the laundry company[®]