


Amana ALE866SBC 03 - DOOR & FRONT, ACCESS & TOP PANELS



Amana [Residential Amana ALE866SBC Dryer Parts](#) Parts Diagram 03 - DOOR & FRONT, ACCESS & TOP PANELS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	503688			Screw, 10B-16 X .34 I
2	501086	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
3	40121401			Panel, Home Hood Back
4	Y503876			Clip, Hold Down
5	40070301CP	37001033		Panel, Top
6	32671	Y014874		Screw, Idler Arm And Sleeve
7	505187			Locator, Panel
8	56080	22001650		Fastener, Spring
9	503661	27001200		Screw
10	500084	40130801		Bracket, Top Mount
11	504005	511056		Seal Front Panel
12	Y504570	W10169313		Switch-Dor
13	503126			Plug, Hinge Hole
14	503656CP			Panel, Front
15	40045301CP			Panel, Access
16	54660	LA-1003		Door Catch Kit

17	37001028		Seal And Liner, Assembly
"	503643W	37001028	Seal And Liner, Assembly
18	500039	510181	Strike Doormetal
19	500223	40116201	Bracket, Door Strike
20	500226		Screw, 8b-16 x 5/8 Tap
21	W10124350	Not Available	NOT REQUIRED PART OR SEE NOTE
"	505328		Wedge, Door Handle
22	503646C	Not Available	PULL, DOOR (BSQ)
"	37001047		Handle, Door
23	37001034		Door, Dryer
"	503654CP	12002135	Door Handle
24	Y503676		Hinge, Door And Top
25	Y504105	Y504105A	Rack-Dry

