


# Amana ALG866SCW (BOM: PALG866SCW) 02 - CONTROL PANEL



Amana Residential Amana ALG866SCW (BOM: PALG866SCW) Dryer Parts Parts Diagram 02 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
2	<a href="#">503674W</a>			Cover, Top
3	<a href="#">62173</a>			Switch, Temperature Select
4	<a href="#">504166</a>			Switch, Signal
5	<a href="#">40084301</a>			Assembly, Moist Sensor Board
6	<a href="#">501523</a>			Support, Circuit Board
7	40112801	<a href="#">R0000411</a>		Timer
8	40012701W		Not Available	ENDCAP (RT-WHT)
9	<a href="#">40039611</a>			Panel, Support
10	<a href="#">40071101W</a>			Panel, Graphic
11	<a href="#">38424W</a>			Switch, Rocker
12	40013601W	<a href="#">37001064</a>		Knob- Time
13	<a href="#">40083301</a>			Medallion
14	40013401W	<a href="#">27001137</a>		Knob Sele
15	<a href="#">40012702W</a>			Endcap

NI	<a href="#">37001006</a>		Harness, Wire Moisture Sensor
"	<a href="#">37001004</a>		Harness, Wire
"	<a href="#">RS3200007</a>		MNL, Service-Home Laundry Dryer
"	37001003	Not Available	MANUAL, USE AND CARE (TRI)

