


Amana CW4202L (BOM: PCW4202L) 02 - AGITATOR & DRIVE BELL



AGITATOR AND DRIVE BELL

Amana [Residential Amana CW4202L \(BOM: PCW4202L\) Washer Parts](#) Parts Diagram 02 - AGITATOR & DRIVE BELL

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	34155	40002101W		Assembly, Fabric Softner
2	33174	40000501W		Agitator, Flex Vane
3	34288	40065102		Screw, Shoulder 1/4
4	36472			O-Ring
5	34504P	R9900189		Kit, Drive Bell And Seal
6	Y00000000		Not Available	SEE NOTE WASHTUB

the laundry company