


Amana CW4202W2 (BOM: PCW4202W2 A) 03 - AGITATOR/DRIVE BELL/SEAL KIT/TUB & HUB



Amana Residential Amana CW4202W2 (BOM: PCW4202W2 A) Washer Parts Parts Diagram 03 - AGITATOR/DRIVE BELL/SEAL KIT/TUB & HUB
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
2	36515			Cap, Agitator
4	35035			Guard, Clothes
5	27202	W10116787		Screw
6	28094			Gasket
7	32998	39371		Filter Lin
8	36425	40016101		Seal, Bell Drive
9	Y29220	40016301		Nut, Lock
10	29728	40008301		Insert, Spline
11	495P3	R9900552		Hub And Seal
12	34518P		Not Available	WASHTUB STAINLESS STEEL
"	33503P	39240P		Wash Tub
13	36472			O-Ring
14	36443P	R9900189		Kit, Drive Bell And Seal
15	34288	40065102		Screw, Shoulder 1/4

