


Amana CW4202W2 (BOM: PCW4202W2 A) 10 - GRAPHIC PANEL, CTRL MTG PLATE AND CTRLS



Amana Residential Amana CW4202W2 (BOM: PCW4202W2 A) Washer Parts Parts Diagram 10 - GRAPHIC PANEL, CTRL MTG PLATE AND CTRLS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y34826		Not Available	DIFFUSER,LAMP-CLEAR
3	23962	W10116760		Screw
4	34904	489355		Screw, 8 X 1/2
5	31239	31239P		Timer 3 Cycle Package
6	501086	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
8	34903		Not Available	PANEL, BACK HOOD (USE 37782)
9	34902P		Not Available	TOP
10	34821		Not Available	CONTROL MOUNTING PLATE
11	37681W		Not Available	PANEL, GRAPHICS (WHITE)
"	36613		Not Available	GRAPHIC PANEL
16	35115			Switch, TemPerature 3 P
17	35010	39035		Switch, Pressure-Var
"	36045	40055101		Switch, Pressure