


**Amana CW4202W2 (BOM: PCW4202W2 A) 11 - GRAPHIC PANEL, CTRL MTG PLATE AND CTRLS**



Amana [Residential Amana CW4202W2 \(BOM: PCW4202W2 A\) Washer Parts](#) Parts Diagram 11 - GRAPHIC PANEL, CTRL MTG PLATE AND CTRLS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y34826		Not Available	DIFFUSER,LAMP-CLEAR
3	23962	<a href="#">W10116760</a>		Screw
4	34904	<a href="#">489355</a>		Screw, 8 X 1/2
5	<a href="#">36607</a>			Timer, 4 Cycle
6	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
8	34903		Not Available	PANEL, BACK HOOD (USE 37782)
9	34902P		Not Available	TOP
10	34821		Not Available	CONTROL MOUNTING PLATE
11	36611		Not Available	PANEL, GRAPHICS
17	36045	<a href="#">40055101</a>		Switch, Pressure