


Amana CW4202W2 (BOM: PCW4202W2 A) 16 - GRAPHIC PANEL, CTRL MTG PLATE AND CTRLS



Amana Residential Amana CW4202W2 (BOM: PCW4202W2 A) Washer Parts Parts Diagram 16 - GRAPHIC PANEL, CTRL MTG PLATE AND CTRLS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
3	23962	<a href="#">W10116760</a>		Screw
4	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
8	34904	<a href="#">489355</a>		Screw, 8 X 1/2
10	34903		Not Available	PANEL, BACK HOOD (USE 37782)
11	34902P		Not Available	TOP
12	34821		Not Available	CONTROL MOUNTING PLATE
19	36045	<a href="#">40055101</a>		Switch, Pressure