


**Amana CW4202W2 (BOM: PCW4202W2 B) 13 - GRAPHIC PANEL, CTRL
MTG PLATE AND CTRLS**



Amana [Residential Amana CW4202W2 \(BOM: PCW4202W2 B\) Washer Parts](#) Parts Diagram 13 - GRAPHIC PANEL, CTRL MTG PLATE AND CTRLS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	34823		Not Available	COVER, TOP
2	23962	W10116760		Screw
3	Y34826		Not Available	DIFFUSER,LAMP-CLEAR
4	34904	489355		Screw, 8 X 1/2
6	501086	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
7	34815		Not Available	PANEL, END R.H. (BLK)
8	34903		Not Available	PANEL, BACK HOOD (USE 37782)
9	34902P		Not Available	TOP
10	34821		Not Available	CONTROL MOUNTING PLATE
12	33817		Not Available	ASSY,TIMER SKIRT-BLACK
13	33897			Knob, Timer-Washer-Blac
14	34816			Panel, End