


Amana CW4202W2 (BOM: PCW4202W2 B) 14 - GRAPHIC PANEL, CTRL  
MTG PLATE AND CTRLS



Amana Residential Amana CW4202W2 (BOM: PCW4202W2 B) Washer Parts Parts Diagram 14 - GRAPHIC PANEL,  
CTRL MTG PLATE AND CTRLS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y34826		Not Available	DIFFUSER,LAMP-CLEAR
3	23962	<a href="#">W10116760</a>		Screw
4	31239	<a href="#">31239P</a>		Timer 3 Cycle Package
5	34904	<a href="#">489355</a>		Screw, 8 X 1/2
6	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
8	34903		Not Available	PANEL, BACK HOOD (USE 37782)
9	34902P		Not Available	TOP
11	34821		Not Available	CONTROL MOUNTING PLATE
16	<a href="#">35115</a>			Switch, TemPerature 3 P
17	36045	<a href="#">40055101</a>		Switch, Pressure