


**Amana CW4202W2 (BOM: PCW4202W2A) 03 - AGITATOR/DRIVE BELL/SEAL KIT/TUB & HUB**



Amana Residential Amana CW4202W2 (BOM: PCW4202W2A) Washer Parts Parts Diagram 03 - AGITATOR/DRIVE BELL/SEAL KIT/TUB & HUB

W2J0255A

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
2	<a href="#">36515</a>			Cap, Agitator
4	<a href="#">35035</a>			Guard, Clothes
5	27202	<a href="#">W10116787</a>		Screw
6	<a href="#">28094</a>			Gasket
7	32998	<a href="#">39371</a>		Filter Lin
8	36425	<a href="#">40016101</a>		Seal, Bell Drive
9	Y29220	<a href="#">40016301</a>		Nut, Lock
10	29728	<a href="#">40008301</a>		Insert, Spline
11	495P3	<a href="#">R9900552</a>		Hub And Seal
12	34518P		Not Available	WASHTUB STAINLESS STEEL
"	33503P	<a href="#">39240P</a>		Wash Tub
13	<a href="#">36472</a>			O-Ring
14	36443P	<a href="#">R9900189</a>		Kit, Drive Bell And Seal
15	34288	<a href="#">40065102</a>		Screw, Shoulder 1/4

