


**Amana CW8413W2 (BOM: PCW8413W2A) 02 - AGITATOR/DRIVE BELL/SEAL KIT/TUB & HUB**



W244P2EA

Amana Residential Amana CW8413W2 (BOM: PCW8413W2A) Washer Parts Parts Diagram 02 - AGITATOR/DRIVE BELL/SEAL KIT/TUB & HUB  
 Click on the part number to view part

| Item | Original Part Number  | Replaced By               | Status | Part Description         |
|------|-----------------------|---------------------------|--------|--------------------------|
| 1    | 36542                 | <a href="#">40002101W</a> |        | Assembly, Fabric Softner |
| 2    | <a href="#">36515</a> |                           |        | Cap, Agitator            |
| 3    | <a href="#">35035</a> |                           |        | Guard, Clothes           |
| 4    | 27202                 | <a href="#">W10116787</a> |        | Screw                    |
| 5    | <a href="#">28094</a> |                           |        | Gasket                   |
| 7    | Y29220                | <a href="#">40016301</a>  |        | Nut, Lock                |
| 8    | 495P3                 | <a href="#">R9900552</a>  |        | Hub And Seal             |
| 9    | 29728                 | <a href="#">40008301</a>  |        | Insert, Spline           |
| 10   | 36425                 | <a href="#">40016101</a>  |        | Seal, Bell Drive         |
| 12   | 36511                 | <a href="#">40008401</a>  |        | Plug, Bell               |
| 13   | <a href="#">36472</a> |                           |        | O-Ring                   |
| 14   | 36443P                | <a href="#">R9900189</a>  |        | Kit, Drive Bell And Seal |
| 15   | 34288                 | <a href="#">40065102</a>  |        | Screw, Shoulder 1/4      |