


**Amana CW8413W2 (BOM: PCW8413W2A) 09 - GRAPHIC PANEL, CTRL  
MTG PLATE AND CTRLS**



W840755A

Amana Residential Amana CW8413W2 (BOM: PCW8413W2A) Washer Parts Parts Diagram 09 - GRAPHIC PANEL, CTRL MTG PLATE AND CTRLS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y34826		Not Available	DIFFUSER,LAMP-CLEAR
2	34824		Not Available	TOP COVER
3	23962	<a href="#">W10116760</a>		Screw
4	34904	<a href="#">489355</a>		Screw, 8 X 1/2
5	<a href="#">36773</a>			Timer, 5 Cycle
6	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
7	34817		Not Available	END CAP(RIGHT)
8	34903		Not Available	PANEL, BACK HOOD (USE 37782)
9	34902_P		Not Available	CABINET TOP
10	34821		Not Available	CONTROL MOUNTING PLATE
11	36611		Not Available	PANEL, GRAPHICS
12	36700		Not Available	TIMER KNOB SKIRT
13	35333		Not Available	TIMER KNOB

14	36701	Not Available	KNOB, TEMP
15	34818	Not Available	END CAP(LEFT)
16	36335	<a href="#">40046601</a>	Switch, Temperature Select
17	36045	<a href="#">40055101</a>	Switch, Pressure
18	35118	<a href="#">40039501</a>	Switch, Speed

