


**Amana CW9203W2 (BOM: PCW9203W2 A) 08 - GRAPHIC PANEL, CTRL  
MTG PLATE & CTRLS**



**GRAPHIC PANEL, CONTROL MOUNTING PLATE AND CONTROLS  
(Models CW9203W2, CW9203W3, LW9203L2 and LW9203W2)**

Amana [Residential Amana CW9203W2 \(BOM: PCW9203W2 A\) Washer Parts](#) Parts Diagram 08 - GRAPHIC PANEL, CTRL MTG PLATE & CTRLS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
"	NOTE:		Not Available	USE OUTER TUB COVER AND GASKET TOOL TO REMOVE 36025P OUTER TUB COVER FROM OUTERTUB AND TO INSTALL 32857 GASKET IN OUTER TUB COVER.
1	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
2	34818W		Not Available	PANEL,END-LH
3	35366WP	<a href="#">R9900570</a>		Control BR
4	23962	<a href="#">W10116760</a>		Screw
5	35038		Not Available	SWITCH/ WHITE
6	<a href="#">34829</a>			Diffuser, Lamp-Clear
7	34841		Not Available	STARTER,FLUORESCENT
"	<a href="#">34836</a>			Assembly, Fluorescent Light
"	34837		Not Available	BULB,FLUORESCENT

8	34824W		Not Available	COVER, TOP (COMPUTOR)
9	36136	<a href="#">39078</a>		Switch- Pr
10	34904	<a href="#">489355</a>		Screw, 8 X 1/2
11	34817W		Not Available	PANEL,END-RH
12	Y00000000		Not Available	SEE NOTE CONTROL HOOD REAR PANEL -- (SEE CABINET TOP PAGE)
13	Y00000000		Not Available	SEE NOTE CABINET TOP -- (SEE CABINET TOP AND CONTROL HOOD REAR PANELPAGE)
14	34822		Not Available	NO LONGER AVAILABLE
15	<a href="#">35312W</a>			Panel, Graphic-Amana
16	<a href="#">35114</a>			Gasket, Electronic Control

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>