


# Amana DA3080 14 - DOOR SAFETY SWITCH



**DOOR SAFETY SWITCH**

Amana [Residential Amana DA3080 Washer Parts](#) Parts Diagram 14 - DOOR SAFETY SWITCH  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">21081</a>			Screw, 10-24 X 1/2 RD H
2	20492	<a href="#">M0270504</a>		Washer
3	02928		Not Available	WASHER
4	Y00000000		Not Available	SEE NOTE DRAIN TUB
5	<a href="#">23591</a>			Diaphragm
6	23592		Not Available	ARM
7	Y02370		Not Available	SCREW, 10-24X15/16 HEX
8	<a href="#">22001</a>			Nut, 10-24 Nylon Hex BR
9	<a href="#">51783</a>			Screw, 6b-20 X 7/8 HeX
10	23540		Not Available	SWITCH
11	23951	<a href="#">M0282009</a>		Nut
12	22783		Not Available	BRACKET