


# Amana DA3821 12 - DOOR SAFETY SWITCH



**DOOR SAFETY SWITCH**

Amana [Residential Amana DA3821 Washer Parts](#) Parts Diagram 12 - DOOR SAFETY SWITCH  
 Click on the part number to view part

| Item | Original Part Number  | Replaced By              | Status        | Part Description        |
|------|-----------------------|--------------------------|---------------|-------------------------|
| 1    | <a href="#">21081</a> |                          |               | Screw, 10-24 X 1/2 RD H |
| 2    | 20492                 | <a href="#">M0270504</a> |               | Washer                  |
| 3    | 02928                 |                          | Not Available | WASHER                  |
| 4    | Y00000000             |                          | Not Available | SEE NOTE DRAIN TUB      |
| 5    | <a href="#">23591</a> |                          |               | Diaphragm               |
| 6    | 23592                 |                          | Not Available | ARM                     |
| 7    | Y02370                |                          | Not Available | SCREW, 10-24X15/16 HEX  |
| 8    | <a href="#">22001</a> |                          |               | Nut, 10-24 Nylon Hex BR |
| 9    | <a href="#">51783</a> |                          |               | Screw, 6b-20 X 7/8 HeX  |
| 10   | 23540                 |                          | Not Available | SWITCH                  |
| 11   | 23951                 | <a href="#">M0282009</a> |               | Nut                     |
| 12   | 22783                 |                          | Not Available | BRACKET                 |