


Amana DA6070 12 - CONTROL PANEL, CONTROL HOOD & CONTROLS



CONTROL PANEL, CONTROL HOOD AND CONTROLS

Amana [Residential Amana DA6070 Washer Parts](#) Parts Diagram 12 - CONTROL PANEL, CONTROL HOOD & CONTROLS

[Click on the part number to view part](#)

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-----------------------|----------------------------|---------------|-------------------------|
| 1 | 23392 | | Not Available | CLIP FOR 26816 KNOB |
| 2 | 23402 | | Not Available | KNOB, CONTROL |
| 3 | 24205 | | | Nut, Knurled 3/8-24 |
| 4 | 25124 | | Not Available | CONTROL HOOD END, LEFT |
| 5 | 25067 | | | Control Panel |
| 6 | 24392 | | Not Available | SWITCH TEMP |
| 7 | 91176 | | | Lockwasher, 3/8 Intshkp |
| 8 | 21302 | | | Switch, Motor-2SP |
| 9 | 25232 | | Not Available | SCREW, 8AB-18X7/8 OVAL |
| 10 | 25123 | | Not Available | CONTROL HOOD END, RIGHT |
| 11 | 25126 | 5303284616 | | Clip |
| 12 | 24858 | | Not Available | ASSY, KNOB-TIMER |
| 13 | 25285 | | Not Available | SETSCREW |
| 14 | 24857 | | Not Available | INDICATOR |
| 15 | 70212 | | | Screw, 8-32 X 5/32 RD H |

| | | | |
|----|-------|---------------|-----------------------|
| 16 | 24859 | Not Available | SLEEVE, SUPPORT ANGLE |
| 17 | 23360 | Not Available | ANGLE |
| 18 | 24828 | Not Available | TIMER |

