


# Amana DA6191 12 - CONTROL PANEL & CONTROLS



## CONTROL PANEL AND CONTROLS

Amana [Residential Amana DA6191 Washer Parts](#) Parts Diagram 12 - CONTROL PANEL & CONTROLS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">24291</a>			Assembly, Knob
2	23402		Not Available	KNOB,CONTROL
3	23392		Not Available	CLIP FOR 26816 KNOB
4	26283		Not Available	CONTROL PANEL
5	24391		Not Available	KNURLED NUT
6	Y00000000		Not Available	SEE NOTE PANEL SUPPORT PLATE
7	24392		Not Available	SWITCH TEMP
8	<a href="#">91176</a>			Lockwasher, 3/8 Intshkp
9	24431		Not Available	SPEED SWITCH
10	26051		Not Available	SWITCH,PRESSURE
11	23962	<a href="#">W10116760</a>		Screw
12	<a href="#">70212</a>			Screw, 8-32 X 5/32 RD H
13	<a href="#">24522</a>			Nut, Speed-8ab-18 C1995
14	24857		Not Available	INDICATOR
15	24858		Not Available	ASSY,KNOB-TIMER
16	25285		Not Available	SETSCREW

17	<a href="#">26318</a>		Screw, 8-32 X 1/4 Set S
18	26321	Not Available	TIMER KNOB
19	<a href="#">26319</a>		Spring
20	26326	Not Available	TIMER KNOB INDICATOR
21	26324	Not Available	TIMER
"	24756	Not Available	TIMER

