


Amana DE3010 07 - CONTROL PANEL, CONTROL HOOD & CONTROLS



CONTROL PANEL, CONTROL HOOD AND CONTROLS

Amana Residential Amana DE3010 Washer Parts Parts Diagram 07 - CONTROL PANEL, CONTROL HOOD & CONTROLS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	25232		Not Available	SCREW,8AB-18X7/8 OVAL
2	25072		Not Available	END CAP, LEFT
3	0054512		Not Available	USE D7602303
4	54038			NUt, Speed U-Type
5	52530W		Not Available	CONTROL HOOD, WHITE
"	52530H		Not Available	CONTROL HOOD, HARVEST GOLD
"	52530A		Not Available	CONTROL HOOD, AVOCADO
6	52539GR		Not Available	CONTROL HOOD REAR COVER, GRAY
7	23222	3177991		Screw
8	25724		Not Available	HEX HEAD SCREW
9	23028		Not Available	GASKET,CONTROL BOX END
10	Y00000000		Not Available	SEE NOTE CABINET TOP
11	20493			Washer, 11/64 ID x 3/8 OD
12	23962	W10116760		Screw

13	91176		Lockwasher, 3/8 Intshkp
14	52624	58813P	Switch W/Instructions
15	25966	Not Available	SPACER,TIMER
16	52610	Not Available	TIMER
17	25073	Not Available	END CAP, RIGHT
18	53768	55882P	Assembly- Switch
19	52947		Nut, Hex 15/32-32
20	52864	500226	Screw, 8b-16 x 5/8 Tap
21	Y0053880	Not Available	ACTUATOR, WATER
22	Y0054441	Not Available	NAMEPLATE, HANDLE
23	24205		Nut, Knurled 3/8-24
24	24857	Not Available	INDICATOR
25	25285	Not Available	SETSCREW
26	24858	Not Available	ASSY,KNOB-TIMER
27	22245	Not Available	xREPLACE
28	22244	Not Available	CLIP,C xREPLACE

