


# Amana DE3011 07 - CONTROL PANEL, CONTROL HOOD & CONTROLS



## CONTROL PANEL, CONTROL HOOD AND CONTROLS

Amana Residential Amana DE3011 Washer Parts Parts Diagram 07 - CONTROL PANEL, CONTROL HOOD & CONTROLS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	25232		Not Available	SCREW,8AB-18X7/8 OVAL
2	25072		Not Available	END CAP, LEFT
3	0054512		Not Available	USE D7602303
4	<a href="#">54038</a>			NUt, Speed U-Type
5	52530W		Not Available	CONTROL HOOD, WHITE
"	52530H		Not Available	CONTROL HOOD, HARVEST GOLD
"	52530A		Not Available	CONTROL HOOD, AVOCADO
6	52539GR		Not Available	CONTROL HOOD REAR COVER, GRAY
7	23222	<a href="#">3177991</a>		Screw
8	25724		Not Available	HEX HEAD SCREW
9	23028		Not Available	GASKET,CONTROL BOX END
10	Y00000000		Not Available	SEE NOTE CABINET TOP
11	<a href="#">20493</a>			Washer, 11/64 ID x 3/8 OD
12	23962	<a href="#">W10116760</a>		Screw

13	<a href="#">91176</a>		Lockwasher, 3/8 Intshkp
14	52624	<a href="#">58813P</a>	Switch W/Instructions
15	25966		Not Available SPACER,TIMER
16	52610		Not Available TIMER
17	25073		Not Available END CAP, RIGHT
18	53768	<a href="#">55882P</a>	Assembly- Switch
19	<a href="#">52947</a>		Nut, Hex 15/32-32
20	52864	<a href="#">500226</a>	Screw, 8b-16 x 5/8 Tap
21	Y0053880		Not Available ACTUATOR, WATER
22	Y0054441		Not Available NAMEPLATE, HANDLE
23	<a href="#">24205</a>		Nut, Knurled 3/8-24
24	24857		Not Available INDICATOR
25	25285		Not Available SETSCREW
26	24858		Not Available ASSY,KNOB-TIMER
27	22245		Not Available xREPLACE
28	22244		Not Available CLIP,C xREPLACE

