


Amana DE3231 08 - CONTROL PANEL & CONTROLS



Amana [Residential Amana DE3231 Washer Parts](#) Parts Diagram 08 - CONTROL PANEL & CONTROLS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	23392		Not Available	CLIP FOR 26816 KNOB
2	23402		Not Available	KNOB,CONTROL
3	24391		Not Available	KNURLED NUT
4	52917		Not Available	CONTROL PANEL
5	Y00000000		Not Available	SEE NOTE PANEL SUPPORT PLATE
6	23406		Not Available	KNURLED NUT
7	91176			Lockwasher, 3/8 Intshkp
8	52623	58032		Switch
9	52947			Nut, Hex 15/32-32
10	52563		Not Available	PUSH-TO-START SWITCH ASSEMBLY
11	52610		Not Available	TIMER
12	23401			Switch
13	23400		Not Available	FERRULE
14	70212			Screw, 8-32 X 5/32 RD H
15	23399		Not Available	SWITCH COLLAR

16	24857	Not Available	INDICATOR
17	25285	Not Available	SETSCREW
18	24858	Not Available	ASSY,KNOB-TIMER
19	23130	Not Available	SWITCH COLLAR

