


Amana DE3790 07 - CONTROL PANEL, CONTROL HOOD & CONTROLS



CONTROL PANEL, CONTROL HOOD AND CONTROLS

Amana Residential Amana DE3790 Washer Parts Parts Diagram 07 - CONTROL PANEL, CONTROL HOOD & CONTROLS

[Click on the part number to view part](#)

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-----------------------|---------------------------|---------------|-------------------------------|
| 1 | 25232 | | Not Available | SCREW,8AB-18X7/8 OVAL |
| 2 | 25072 | | Not Available | END CAP, LEFT |
| 3 | Y54971 | | Not Available | CONTROL PANEL |
| 4 | 54038 | | | NUt, Speed U-Type |
| 5 | 52530W | | Not Available | CONTROL HOOD, WHITE |
| " | 52530H | | Not Available | CONTROL HOOD, HARVEST GOLD |
| " | 52530A | | Not Available | CONTROL HOOD, AVOCADO |
| 6 | 52539GR | | Not Available | CONTROL HOOD REAR COVER, GRAY |
| 7 | 23222 | 3177991 | | Screw |
| 8 | 25724 | | Not Available | HEX HEAD SCREW |
| 9 | 23028 | | Not Available | GASKET,CONTROL BOX END |
| 10 | Y00000000 | | Not Available | SEE NOTE CABINET TOP |
| 11 | 20493 | | | Washer, 11/64 ID x 3/8 OD |
| 12 | 23962 | W10116760 | | Screw |

| | | | |
|----|-----------------------|------------------------|---------------------------------|
| 13 | 91176 | | Lockwasher, 3/8 Intshkp |
| 14 | 52624 | 58813P | Switch W/Instructions |
| 15 | 25966 | | Not Available SPACER,TIMER |
| 16 | 52610 | | Not Available TIMER |
| 17 | 25073 | | Not Available END CAP, RIGHT |
| 18 | 53768 | 55882P | Assembly- Switch |
| 19 | 52947 | | Nut, Hex 15/32-32 |
| 20 | 52864 | 500226 | Screw, 8b-16 x 5/8 Tap |
| 21 | Y0053880 | | Not Available ACTUATOR, WATER |
| 22 | Y0054441 | | Not Available NAMEPLATE, HANDLE |
| 23 | 24205 | | Nut, Knurled 3/8-24 |
| 24 | 24857 | | Not Available INDICATOR |
| 25 | 25285 | | Not Available SETSCREW |
| 26 | 24858 | | Not Available ASSY,KNOB-TIMER |
| 27 | 22245 | | Not Available xREPLACE |
| 28 | 22244 | | Not Available CLIP,C xREPLACE |

