


# Amana DE3790 10 - DRUM LIGHT & COVER PLATE



[Amana Residential Amana DE3790 Washer Parts](#) Parts Diagram 10 - DRUM LIGHT & COVER PLATE  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y54608	<a href="#">31001575</a>		Bulb, Cylinder Light
2	Y0054609	<a href="#">M0270519</a>		Washer
3	54610		Not Available	PLUG BUTTON
4	Y00000000		Not Available	SEE NOTE FRONT FRAME AND AIR SHROUD