


Amana DG1030 10 - DOOR RELEASE



DOOR RELEASE

Amana [Residential Amana DG1030 Washer Parts](#) Parts Diagram 10 - DOOR RELEASE

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	51065		Not Available	DOOR RELEASE SPRING
2	51786		Not Available	PLUG
3	51841		Not Available	DOOR RELEASE PIN ASSEMBLY
4	02578			Pin, Cotter
5	51041		Not Available	DOOR RELEASE LEVER
6	51161		Not Available	PIN,ROLL 1/8 X 3/4
7	51121			Door Release Spacer
8	51837		Not Available	DOOR RELEASE ROD
9	51045		Not Available	PEDAL HINGE PIN
10	51046		Not Available	NYLON WASHER
11	51271		Not Available	NUT
12	51802			Pedal, Foot
13	51844		Not Available	DOOR RELEASE ASSEMBLY
14	51246		Not Available	SCREW
15	51052		Not Available	DOOR RELEASE BRACKET