


Amana DG1030 11 - DRUM LIGHT & COVER PLATE



Amana [Residential Amana DG1030 Washer Parts](#) Parts Diagram 11 - DRUM LIGHT & COVER PLATE
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	51070			Lens, Drum Light
2	Y51887		Not Available	BULB RECEPTACLE
3	21608	A3167501		Lamp Oven, Int.
4	Y51788		Not Available	SPEED NUT
5	53911		Not Available	COVER PLATE
6	Y00000000		Not Available	SEE NOTE FRONT FRAME AND AIR SHROUD
7	51784		Not Available	SCREW, 10B-16 X 1/2 HEX