


Amana DG1031 08 - CABINET TOP & CONTROL PANEL



Amana [Residential Amana DG1031 Washer Parts](#) Parts Diagram 08 - CABINET TOP & CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
"	NOTE:		Not Available	HOUSING AND PANEL ASSEMBLY WILL BE SUPPLIED WHENEVER 52963GR LINT SCREEN HOUSING OR 53058GR INNER DOOR PANEL IS ORDERED
1	51778			Screw, 8b-18 X 1/2 RD H
2	Y02787		Not Available	SCREW, 6-32 X 1/4 RD HDxREPLACE
3	22450		Not Available	TIMER DIAL
4	20310		Not Available	SCREW, 8-32 X 1/4 HEX S
5	22478		Not Available	TIMER KNOB ASSEMBLY
6	52947			Nut, Hex 15/32-32
7	53738		Not Available	STICKER, PUSH-TO-START
8	51236	488130		Nut
9	Y20278		Not Available	LOCKWASHER
10	21903	211881		Grommet, Cord Part Not Used- Gas Models Only

11	0054560		Not Available	USE D7755902
12	03630		Not Available	SCREW,6-32 X 3/8 ROUND
13	52660W		Not Available	ACCESS DOOR, WHITE
14	51351			Hinge, Rear
15	51350			Hinge, Front
16	20747	500824		Screw, 1/4-20 Unc Hex
17	53733W		Not Available	CABINET TOP, WHITE
18	02431			Lockwasher, 1/4 Ext Shk
19	20275	27001225		Nut, Jam Mid Lock 1/4-20
20	51355	51-355		5500w/240v, 13-23/32, Low Watt
21	52614		Not Available	TOP BAFFLE ASSEMBLY
22	22678			Nut, Nylon
23	51508		Not Available	POWER CORD
24	22649			Screw, 8-32 X 13/32 FI
25	53445			Bumper
26	53768	55882P		Assembly- Switch
27	52594		Not Available	TIMER
28	23007		Not Available	CAGED NUT
29	Y0052551		Not Available	BACKER, DOOR
30	70212			Screw, 8-32 X 5/32 RD H
31	52557		Not Available	CONTROL PLATE

