


# Amana DG3021 10 - CONTROL PANEL, CONTROL HOOD & CONTROLS



## CONTROL PANEL, CONTROL HOOD AND CONTROLS

Amana [Residential Amana DG3021 Washer Parts](#) Parts Diagram 10 - CONTROL PANEL, CONTROL HOOD & CONTROLS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	25232		Not Available	SCREW,8AB-18X7/8 OVAL
2	25072		Not Available	END CAP, LEFT
3	0054512		Not Available	USE D7602303
4	<a href="#">54038</a>			NUt, Speed U-Type
5	52530W		Not Available	CONTROL HOOD, WHITE
"	52530H		Not Available	CONTROL HOOD, HARVEST GOLD
"	52530A		Not Available	CONTROL HOOD, AVOCADO
6	52539GR		Not Available	CONTROL HOOD REAR COVER, GRAY
7	23222	<a href="#">3177991</a>		Screw
8	25724		Not Available	HEX HEAD SCREW
9	23028		Not Available	GASKET,CONTROL BOX END
10	Y00000000		Not Available	SEE NOTE CABINET TOP
11	<a href="#">20493</a>			Washer, 11/64 ID x 3/8 OD
12	23962	<a href="#">W10116760</a>		Screw

13	<a href="#">91176</a>		Lockwasher, 3/8 Intshkp
14	53380	Not Available	TEMPERATURE SELECTOR SWITCH
15	25966	Not Available	SPACER,TIMER
16	52594	Not Available	TIMER
17	25073	Not Available	END CAP, RIGHT
18	53768	<a href="#">55882P</a>	Assembly- Switch
19	<a href="#">52947</a>		Nut, Hex 15/32-32
20	52864	<a href="#">500226</a>	Screw, 8b-16 x 5/8 Tap
21	Y0053880	Not Available	ACTUATOR, WATER
22	Y0054441	Not Available	NAMEPLATE, HANDLE
23	24857	Not Available	INDICATOR
24	25285	Not Available	SETSCREW
25	24858	Not Available	ASSY,KNOB-TIMER
26	<a href="#">24205</a>		Nut, Knurled 3/8-24
27	22245	Not Available	xREPLACE
28	22244	Not Available	CLIP,C xREPLACE

