


Amana DG3021 22 - REAR FRAME & FRAME BASE



REAR FRAME AND FRAME BASE

Amana [Residential Amana DG3021 Washer Parts](#) Parts Diagram 22 - REAR FRAME & FRAME BASE

[Click on the part number to view part](#)

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|------------------------|--------------------------|---------------|--------------------------------|
| 1 | 20354 | | Not Available | BUMPER PAD |
| 2 | Y00000000 | | Not Available | SEE NOTE GROUND WIRE, GREEN |
| 3 | 51784 | | Not Available | SCREW, 10B-16 X 1/2 HEX |
| 4 | 51780 | 3390631 | | Screw, 10-16 X 3/8 |
| 5 | 21685 | 40038001 | | Bumper |
| 6 | 51818 | | Not Available | SUPPORT CHANNEL, RIGHT OR LEFT |
| 7 | Y0054053 | Y0301205 | | ELement- L |
| 8 | Y52079 | | | Bearing, Drum Shaft |
| 9 | 51826 | | Not Available | COVER, BEARING |
| 10 | 03189 | | | LoCkwasher, 1/4 Std-C P |
| 11 | 53589 | 8204624 | | Bolt |
| 12 | 53132 | | Not Available | SHAFT, DRUM |
| 13 | 70061 | | | Ring, Retaining |
| 14 | Y52564 | | | Washer |
| 15 | 52574 | | Not Available | FRAME, REAR |

| | | | |
|----|--------|-------------------------|------------------------|
| 16 | Y52572 | Not Available | FRAME BASE |
| 17 | 52794 | 62739 | Nut, Lock |
| 18 | 70282 | Y314137 | Foot, Rubber |
| 19 | Y52696 | Y305086 | Adjustable Leg And Nut |

