


# Amana DG3240 08 - CONTROL PANEL, CONTROL HOOD & CONTROLS



## CONTROL PANEL, CONTROL HOOD AND CONTROLS

Amana [Residential Amana DG3240 Washer Parts](#) Parts Diagram 08 - CONTROL PANEL, CONTROL HOOD & CONTROLS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	22244		Not Available	CLIP,C xREPLACE
2	22245		Not Available	xREPLACE
3	<a href="#">24205</a>			Nut, Knurled 3/8-24
4	25124		Not Available	CONTROL HOOD END, LEFT
5	25126	<a href="#">5303284616</a>		Clip
6	Y0053958	<a href="#">59001951</a>		Fuse- Ther
7	<a href="#">91176</a>			Lockwasher, 3/8 Intshkp
8	53380		Not Available	TEMPERATURE SELECTOR SWITCH
9	25232		Not Available	SCREW,8AB-18X7/8 OVAL
10	53768	<a href="#">55882P</a>		Assembly- Switch
11	<a href="#">52947</a>			Nut, Hex 15/32-32
12	52610		Not Available	TIMER
13	25123		Not Available	CONTROL HOOD END, RIGHT
14	<a href="#">24522</a>			Nut, Speed-8ab-18 C1995

15	53446W	Not Available	CONTROL HOOD, WHITE
"	53446H	Not Available	CONTROL HOOD, HARVEST GOLD
"	53446A	Not Available	CONTROL HOOD, AVOCADO
"	53446C	Not Available	CONTROL HOOD, COPPERTONE
16	23028	Not Available	GASKET, CONTROL BOX END
17	<a href="#">20493</a>		Washer, 11/64 ID x 3/8 OD
18	23962	<a href="#">W10116760</a>	Screw
19	Y00000000	Not Available	SEE NOTE CABINET TOP
20	23425	Not Available	WASHER, 7/32 ID X 7/16 ODX.
21	52912	Not Available	PANEL SUPPORT BRACKET
22	24858	Not Available	ASSY, KNOB-TIMER
23	24859	Not Available	SLEEVE, SUPPORT ANGLE
24	<a href="#">70212</a>		Screw, 8-32 X 5/32 RD H
25	25285	Not Available	SETSCREW
26	24857	Not Available	INDICATOR

