


# Amana DG3261 10 - CONTROL PANEL & CONTROLS



**CONTROL PANEL AND CONTROLS**

Amana [Residential Amana DG3261 Washer Parts](#) Parts Diagram 10 - CONTROL PANEL & CONTROLS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y00000000		Not Available	SEE NOTE PANEL SUPPORT PLATE
2	<a href="#">91176</a>			Lockwasher, 3/8 Intshkp
3	52623	<a href="#">58032</a>		Switch
5	23962	<a href="#">W10116760</a>		Screw
6	<a href="#">52947</a>			Nut, Hex 15/32-32
7	53563		Not Available	SWITCH,DOOR RELEASE
8	52610		Not Available	TIMER
9	<a href="#">70212</a>			Screw, 8-32 X 5/32 RD H
10	23406		Not Available	KNURLED NUT
11	24857		Not Available	INDICATOR
12	25285		Not Available	SETSCREW
13	24858		Not Available	ASSY,KNOB-TIMER
14	23130		Not Available	SWITCH COLLAR
15	23392		Not Available	CLIP FOR 26816 KNOB
16	23402		Not Available	KNOB,CONTROL
17	Y0053888		Not Available	SCREW, HOUSING

