


Amana DG3280 09 - CLOTHES DRUM



CLOTHES DRUM

Amana [Residential Amana DG3280 Washer Parts](#) Parts Diagram 09 - CLOTHES DRUM
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	51881			Seal, Front
2	50169			Strap, Retainer
3	53135			Assembly, Drum
4	52310			Spring
5	50781			Strap, Seal
6	51883A			Assembly, Seal
7	51201		Not Available	CLIP
8	50168			Spring