


# Amana DG3300 10 - DRUM LIGHT & COVER PLATE



[Amana Residential Amana DG3300 Washer Parts](#) Parts Diagram 10 - DRUM LIGHT & COVER PLATE  
[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
5	53911		Not Available	COVER PLATE
6	Y00000000		Not Available	SEE NOTE FRONT FRAME AND AIR SHROUD
7	51784		Not Available	SCREW, 10B-16 X 1/2 HEX