


Amana DG3331 10 - CONTROL PANEL & CONTROLS



CONTROL PANEL AND CONTROLS

Amana [Residential Amana DG3331 Washer Parts](#) Parts Diagram 10 - CONTROL PANEL & CONTROLS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	Y00000000		Not Available	SEE NOTE PANEL SUPPORT PLATE
2	91176			Lockwasher, 3/8 Intshkp
3	52623	58032		Switch
4	53516		Not Available	BUZZER
5	23962	W10116760		Screw
6	52947			Nut, Hex 15/32-32
7	53563		Not Available	SWITCH, DOOR RELEASE
8	53466		Not Available	TIMER
9	70212			Screw, 8-32 X 5/32 RD H
10	23406		Not Available	KNURLED NUT
11	24857		Not Available	INDICATOR
12	25285		Not Available	SETSCREW
13	24858		Not Available	ASSY, KNOB-TIMER
14	23130		Not Available	SWITCH COLLAR
15	23392		Not Available	CLIP FOR 26816 KNOB
16	23402		Not Available	KNOB, CONTROL

17 0054749

Not Available

HINGE PIN

18 24391

Not Available

KNURLED NUT

19 [23407](#)

Nut, Speed-8A Tinn C15

