


# Amana DG3350 10 - CONTROL PANEL, CONTROL HOOD & CONTROLS



## CONTROL PANEL, CONTROL HOOD AND CONTROLS

Amana [Residential Amana DG3350 Washer Parts](#) Parts Diagram 10 - CONTROL PANEL, CONTROL HOOD & CONTROLS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	Y0053962		Not Available	LATCH DR K
2	<a href="#">91176</a>			Lockwasher, 3/8 Intshkp
3	53380		Not Available	TEMPERATURE SELECTOR SWITCH
4	25232		Not Available	SCREW,8AB-18X7/8 OVAL
5	53768	<a href="#">55882P</a>		Assembly- Switch
6	<a href="#">52947</a>			Nut, Hex 15/32-32
7	52167		Not Available	TIMER
8	25123		Not Available	CONTROL HOOD END, RIGHT
9	<a href="#">24522</a>			Nut, Speed-8ab-18 C1995
10	53446H		Not Available	CONTROL HOOD, HARVEST GOLD
"	53446C		Not Available	CONTROL HOOD, COPPERTONE
"	53446W		Not Available	CONTROL HOOD, WHITE
"	53446A		Not Available	CONTROL HOOD, AVOCADO

11	23028		Not Available	GASKET,CONTROL BOX END
12	<a href="#">20493</a>			Washer, 11/64 ID x 3/8 OD
13	23962	<a href="#">W10116760</a>		Screw
14	Y00000000		Not Available	SEE NOTE CABINET TOP
15	23425		Not Available	WASHER,7/32IDX7/16ODX.
16	52912		Not Available	PANEL SUPPORT BRACKET
17	24859		Not Available	SLEEVE,SUPPORT ANGLE
18	<a href="#">70212</a>			Screw, 8-32 X 5/32 RD H
19	25285		Not Available	SETSCREW
20	24858		Not Available	ASSY,KNOB-TIMER
21	24857		Not Available	INDICATOR
22	23392		Not Available	CLIP FOR 26816 KNOB
"	22244		Not Available	CLIP,C xREPLACE
23	<a href="#">24205</a>			Nut, Knurled 3/8-24
24	22245		Not Available	xREPLACE
25	25124		Not Available	CONTROL HOOD END, LEFT
26	25126	<a href="#">5303284616</a>		Clip

