


# Amana DG3680 11 - DOOR RELEASE



## DOOR RELEASE

Amana [Residential Amana DG3680 Washer Parts](#) Parts Diagram 11 - DOOR RELEASE

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	51065		Not Available	DOOR RELEASE SPRING
2	51786		Not Available	PLUG
3	51841		Not Available	DOOR RELEASE PIN ASSEMBLY
4	<a href="#">02578</a>			Pin, Cotter
5	51041		Not Available	DOOR RELEASE LEVER
6	51161		Not Available	PIN,ROLL 1/8 X 3/4
7	<a href="#">51121</a>			Door Release Spacer
8	51837		Not Available	DOOR RELEASE ROD
9	51045		Not Available	PEDAL HINGE PIN
10	51046		Not Available	NYLON WASHER
11	51271		Not Available	NUT
12	<a href="#">51802</a>			Pedal, Foot
13	51844		Not Available	DOOR RELEASE ASSEMBLY
14	51246		Not Available	SCREW
15	51052		Not Available	DOOR RELEASE BRACKET